


IceniCAM Information Service



“SCOTT” CYC-AUTO

== SPARE PARTS BOOK ==

THE CYC-AUTO WORKS CO.,

441 ~~15~~ BRUNEL ROAD,

EAST ACTON,

LONDON, W.3.

349
52
—
4

MARK II T. ENGINE GROUP

PART NO.	DESCRIPTION	£ s. d.
2	Compression Release Body	2 8
3	Washer for ditto	2
4	Valve	1 6
5	Spring	9
6	Spring Cap	9
8	Peg for ditto	2
9	Frame Fixing Bolt	1 0
10	Frame Fixing Nut	2
11	Spring Washer for ditto	2
301	Crankcase Forward Half	1 12 0
302	Crankcase Rear Half	1 13 6
303	Crankcase Stud (Long)	8
304	Nut for Stud	2
305	Spring Washer for ditto	2
306	Stud for Crankcase and Cylinder... ..	9
307	Nut for ditto	4
308	Crankcase to Cylinder Packing	4
309	Bronze Bush for Crankcase Forward Half	6
310	Bronze Bush for Crankcase Rear Half	6
311	Washer for Drain Plug	2
312	Drain Plug	4
316	Crankcase Stud (Short)	6
400	Crank Genimag End	1 8 6
402	Crank Rear End	1 2 0
403	Crank Pin	10 0 17/-
404	Ball Bearing R.L.6. Self Aligning (Front)	15 0
405	Ball Bearing R.L.S.6. Rigid (Rear)	15 0
501	Connecting Rod Comp with Bush	17 10 18/6
502	Connecting Rod Small End Bush	1 0 2/-
504	Connecting Big End Rollers. Per set of 12	4 0
601	Piston	16 0
602	Piston Ring Tapered. Each	2 2
604	Gudgeon Pin	3 2
605	Gudgeon Pin Circlips	4
606	Over Size Pistons 0.020"	16 9
607	Over Size Rings 0.020"	2 4
608	Gasket for Exhaust Pipe	1 0
609	Stud	9
610	Stud Nut	4
611	Lock Washer	2
612	Carb. Flanged Stub	12 6
613	Stud for ditto	9
614	Nut	4
615	Lock Washer	2
616	Carb. Stub Flange Gasket	4
699	Cylinder	2 4 6
701	Cylinder Head	1 6 8
702	Gasket	2 0
703	Long Stud	9
704	Long Nut	4
705	Short Nut	3
706	Stud Washers	2
716	Short Stud	4
717	Exhaust Pipe (Right)	12 0
718	Exhaust Pipe (Left)... ..	12 0

MARK II T. ENGINE GROUP—continued.

PART NO.	DESCRIPTION	£	s.	d.
719	Clip Exhaust Pipe to Silencer	2	0	
720	Bolt		9	
721	Nut		4	
722	Lock Washer		2	
723	Tubular Silencer	16	0	
724	Fixing Strap	1	2	
725	Bolt		9	
726	Nut		4	
727	Lock Washer		2	
728	Fixing Bolt. 724 to Chain Stay		9	
729	Nut		4	
730	Lock Washer		2	
731	Flywheel Casing	12	0	
732	Fixing Counter Sunk Headed Screws		6	
733	Fixing Hex. Headed Bolts		9	
734	Lock Washers		2	
735	Studs for Stator Plate		9	
736	Nuts		4	
737	Lock Washers		2	
	Over Size Re-Bored Cylinders (Exchange)	1	10	0

CLUTCH GROUP

PART NO.	DESCRIPTION	£	s.	d.
3101	Clutch Driving Flange	13	6	
3102	Thrust Ball Race	4	0	
3103	Thrust Ball Race Balls $\frac{5}{32}$ "—Per set of 26		10	
3104	Circlip for Flange		3	
3105	Clutch Spring	2	0	
3106	Clutch Withdrawal Sleeve	8	6	
3107	Clutch Drive Lock Nut	4	9	
3108	Clutch Drive Lock Nut Lock Screw		3	
3109	Clutch Drive Lock Bush		10	
3110	Clutch Friction Rings	1	4	
3111	Clutch Plate (Large)	1	4	
3112	Clutch Plate (Small)	1	4	
3113	Clutch Driver Member	18	9	
3114	Clutch Driving Flange Key		3	
3115	Clutch Housing	5	6	
3117	Clutch Brake Lining	2	9	
3118	Rivets for ditto		4	
3119	Clutch Withdrawal Yoke	8	0	
3120	Bush for ditto	1	1	
3122	Clutch Thrust Ring	7	4	
3123	Fulcrum Pin for ditto		2	
3124	Clutch Operating Lever	6	6	
3128	Clutch Operating Lever Locking Screw and Nut		8	
3132	Clutch Driving Shaft	12	6	
3135	Clutch Driving Shaft Bush	2	3	

CARBURETTOR GROUP

PART NO.	DESCRIPTION	£	s.	d.
1546	Amal Carburettor and Control	2	0	6
1547	Carburettor Clamp	2	0	0
1548	Carburettor Clamp Screw	9	0	0
1549	Throttle Lever complete	2	2	4
1555	Base Clip	3	3	3
1556	Clip Screw	18	9	9
1557	Clip Screw Nut	3	9	9
1560	Throttle Cable complete	10	10	2
1561	Carburettor Body	2	2	2
1562	Float Chamber Cover	3	6	3
1563	Tickler	3	9	6
1564	Tickler Bush	1	6	3
1565	Tickler Spring	2	3	3
1566	Tickler Cotter Pin	3	9	9
1567	Cork Washer	1	6	3
1568	Float and Needle	2	3	3
1569	Jet Chamber Plug	18	9	9
1570	Jet Chamber Plug Fibre Washer	2	9	4
1572	Air Filter (Gauze Type)	2	3	3
1576	Throttle	2	9	4
1577	Throttle Spring	2	3	4
1578	Throttle Chamber Cap	6	6	3
1579	Cable Adjuster and Nut	4	4	3
1581	Jet Chamber Plug Screw and Washer	2	9	3
1582	Throttle Valve Guide Screw	2	9	9
1584	Needle Adjusting Washer... ..	2	9	9
1585	Strangler Pull Rod	3	3	2
1586	Strangler Shutter	3	3	2
1587	Strangler Shutter Pin	2	3	3
1588	Strangler Shutter Split Pin	2	3	3
1592	Strangler Pull Rod Friction Spring	2	0	6
1593	Taper Needle	2	6	8
1594	Needle Jet. No. 1075	1	6	8
1595	Main Jet. No. 55	1	6	8
1596	Jet Key	1	6	8

GENI-MAG GROUP

PART NO.	DESCRIPTION	£	s.	d.
1643	Spark Plug	5	0	0
1649	Flywheel	2	9	0
1650	Flywheel Key	1	2	2
1651	Flywheel Locking Nut	1	2	2
1652	Flywheel Nut Lock Washer	4	8	2
1653	Breaker Cam (Parallel fitting)	2	2	2
1654	Cam Key	2	2	2
1655	Cam Screw	2	2	2
1656	Cam Screw Lock Washer	2	2	2
1656	L.T. Terminal Screw Nut Lock Washer	2	2	2
1657	Cam Screw Lock Ring	2	2	2
1658	Cam Oil Pad	2	2	2

GENI-MAG GROUP—continued.

PART NO.	DESCRIPTION	£	s.	d.
1659	Bearing Brush	1		2
1660	H.T. Coil Group	12		6
1661	Coil Gaskets			4
1662	H.T. Terminal	3		0
1663	H.T. Terminal Screws			2
1664	H.T. Terminal Screw Lock Washer			2
1664	Breaker Box Cover Screw Lock Washer			2
1664	Fixed Contract Screw Lock Washer			2
1664	Breaker Arm Spring Block Fixing Screw Lock Washer			2
1664	Breaker Arm Bracket Screw Lock Washer			2
1665	H.T. Lead Wire Unit	2		3
1666	H.T. Terminal Gasket			2
1667	H.T. Lead Wire Group 6½"	1		9
1668	H.T. Rubber Protector			6
1669	Breaker Box Cover			9
1670	Capacitor Screw Condenser			2
1671	Capacitor Condenser	5		6
1672	Breaker Arm	5		9
1673	Breaker Arm Spring Screw			2
1673	Breaker Arm Spring Block Screw			2
1674	Breaker Box Cover Screw			2
1675	Stator Plate Unit	15		0
1676	Breaker Arm Washer (1/32" thick)			2
1677	Breaker Arm Washer (.020" thick)			2
1678	Breaker Arm Shim (.005" thick)			2
1679	Fixed Contact	2		4
1680	Fixed Contact Screw			2
1681	Fixed Contact Screw Washer			2
1681	L.T. Terminal Screw Washer			2
1682	Breaker Arm Spring Block Screw Nut			2
1683	Core Group		4	8
1684	Coil and Core Group	2	0	0
1685	Breaker Arm Spring Block		1	4
1686	Core Stud Nut			2
1687	Core Stud Nut Lock Washer			2
1687	Capacitor Fixing Nut Lock Washer			2
1688	L.T. Terminal Screw			2
1689	L.T. Terminal Screw Bushing			2
1690	Fixed Contact Screw Nut			2
1691	L.T. Terminal Screw Insulating Screw Washer			2
1692	L.T. Screw Fixing Nut			2
1693	(Condenser) Fixing Nut			2
1694	L.T. Terminal Screw Nut			2
1695	L.T. Terminal Screw Insulating Washer			2
1696	L.T. Coil Group	8		0
1697	L.T. Coil Group	8		0
1698	L.T. Coil Group (pair)	16		0
1699	Breaker Arm Lock			2

FRAME GROUP

PART NO.	DESCRIPTION	£	s.	d.
1704	Frame 19"	9	5	6
1705	Goods Carrier Frame	9	10	6
1706	Baskets to Requirements	On application		
1707	Basket, Carrier	2	15	0
1708	Fixing Bolts. $\frac{5}{16}$ " \times 3" B.S.F.	1	0	0
1709	Front Forks	15	0	0
1710	Girders (pair)	8	0	0
1711	Top Clip and Race	3	6	0
1712	Bolt and Nut	1	0	0
1712A	Distance Pieces	3	0	0
1713	Rear Carrier	6	6	0
1714	Rear Carrier Supports	1	3	0
1715	Bolts	4	0	0
1716	Nuts	5	0	0
1717	Lock Washers	2	0	0
1722	Crown Race	1	1	0
1723	Bottom Cup in Steering Head	9	0	0
1724	Bottom Cup Balls. $\frac{3}{16}$ ", 22 per set	9	0	0
1725	Top Race in Steering Head	9	0	0
1726	Top Cup Screws on Fork	1	8	0
1727	Top Cup Balls, $\frac{3}{8}$ ", 25 per set	9	0	0
1728	Crown Race for Superior only	1	3	0
1729	Bottom Cup for Superior only	1	6	0
1730	Balls, Top and Bottom. $\frac{3}{16}$ "	1	6	0
1732	Seat Stay (Right or Left Hand)	7	9	0
1733	Seat Lug Bolt and Washer, $\frac{5}{16}$ ". B.S.F. 2 $\frac{1}{2}$ "	6	0	0
1734	Seat Stay Distance Piece	4	0	0
1735	Seat Stay Bottom End Bolt and Nut	4	0	0
1736	Rear Stand	17	6	0
1739	Rear Stand Pivot Screw	3	0	0
1740	Rear Stand Pivot Screw Washer	3	0	0
1741	Stand Spring Clip	1	6	0
1742	Pivot	6	0	0
1743	Spring	9	0	0
1745	Cotter Pin	1	0	0

SPRING FORK GROUP

PART NO.	DESCRIPTION	£	s.	d.
1759	Spring Fork complete	3	10	0
1760	Girder complete	2	0	0
1764	Column	8	6	0
1765	Column Lock Nut	1	0	0
1766	Top Clip	7	6	0
1773	Top Spindle	1	6	0
1774	Bottom Spindle	1	6	0
1775	Nut for Top or Bottom Spindle	4	0	0
1776	Washer for Top or Bottom Spindle	2	0	0
1777	Top Link	2	2	0
1778	Bottom Link	2	2	0
1779	Fork Spring	5	9	0

SPRING FORK GROUP—continued.

PART NO.	DESCRIPTION	£	s.	d.
1780	Spring Bolt (Short) and Nut	6
1781	Spring Bolt (Long) and Nut	6
1782	Grease Nipple	3
1786	Bolt for Brake Anchorage	3
1787	Nut for ditto	2
1788	Distance Piece	3
1789	Lock Washer	2
1790	Lamp Bracket	9
1791	Bolt for ditto, $\frac{1}{4}$ " \times $\frac{1}{2}$ " B.S.F.	3
1792	Nut for ditto, $\frac{1}{4}$ " B.S.F.	2
1793	Lock Washer, $\frac{1}{4}$ " Shakeproof	2
1794	Bolt for Top Clip	1 6
1795	Nut for ditto	6

MUDGUARD GROUP

PART NO.	DESCRIPTION	£	s.	d.
1802	Carrier	6 6
1804	Carrier Support	1 3
1810	Front Bolt Rear Guard	4
1811	Lock Washer	3
1812	Power Chain Guard, Black or Silver	7 6
1813	Power Chain Guard Front Support	4
1814	Top Bolt	4
1815	Lock Washer	3
1816	Rear Support	4
1817	Rear Support Bolt	4
1818	Nut	3
1819	Lower Hexagon Support	9
1820	Nut	3
1821	Front Guard Front Stay	2 2
1822	Bolts for Stays	3
1823	Nuts	2
1825	Front Mudguard, Black or Silver	9 0
1826	Rear Stay	2 2
1827	Bolts	3
1828	Nuts	2
1837	Brackets for Front Number Plate	1 0
1838	Bolts for ditto	3
1839	Nut	2
1840	Rear Mudguard, Black or Silver	10 6
1841	Stay for ditto	2 2
1842	Front Number Plate	1 9
1843	Rear Number Plate	3 6
1844	Bolts	4
1845	Nuts	3
1846	Lock Washers	3
1847	Support Front Guard	3
1848	Nut $\frac{1}{4}$ " B.S.F. for ditto	2
1849	Washer $\frac{1}{4}$ " for ditto	2
1850	Front Number Plate Screws	3
1851	Nuts for ditto	2
1852	Mudflaps	3 0

HANDLEBAR GROUP

PART NO.	DESCRIPTION	£	s.	d.
	Handlebar complete, Two Brake Levers	2	0	0
1903	Grips	2	2	2
1904	Handlebars less Fittings	17	0	0
1911	Release Valve Lever complete	3	6	6
1921	Cable for Release Valve	2	0	1
1936	Expander Bolt	1	1	4
1937	Expander Nut	3	2	6
1938	Washer for ditto	5	0	9
1948	Front Brake Cable	5	9	4
1949	Rear Brake Cable	1	4	4
1950	Clutch or Brake Levers complete	2	9	3
1951	Lever Saddle	6	2	9
1952	Bolt for ditto	2	9	3
1953	Nut	2	9	2
1954	Clip	3	9	2
1955	Clip Screw	6	9	9
1956	Clip Screw Nut	2	9	2
1957	Clutch Cable and Adjuster	9	9	2
1958	Adjuster	2	9	2
1959	Adjuster Lock Nut	2	9	2

LAMPS

PART NO.	DESCRIPTION	£	s.	d.
2002	Head Lamp	15	6	2
2006	Main Bulb Holder	2	2	3
2007	Pilot Bulb Holder	1	3	3
2011	Glass	5	0	1
2012	Tail Lamp complete	1	9	4
2013	Fixing Plate, 3 holes	2	2	2
2014	Body Clip	2	2	8
2014A	Body Clip Bolt, Nut and Washer	4	2	8
2015	Fixing Screws	2	2	4
2016	Nuts	1	8	4
2021	Lantern and Ruby Reflector	2	2	2
2022	Tail Lamp Bulb Holder	1	8	4
2023	G.M. Head Bulb, 6v., 6w. Tax 4d.	10	2	9
2024	G.M. Pilot Bulb, 4v, 3a. Tax 1d.	10	2	9
2025	G.M. Tail Bulb, 6v., 0.04a. Tax 1½d.	2	9	2
2028	Earth Wire	2	9	2
2029	Earth Wire Screw	2	9	2

PETROL TANK GROUP

PART NO.	DESCRIPTION	£	s.	d.
2101	Circular Petrol Tank, Oil Measure and Filler Cap	1	5	0
2102	Tank only	1	3	0
2103	Oil Measure and Filler Cap	2	2	
2104	Washer			3
2105	Petrol Tap with Reserve	9	4	
2106	Petrol Tap, Single Way	4	6	
2107	Fibre Washer for 2106			2
2108	Fibre Washer for 2105			2
2109	Petrol Pipe	4	0	
2110	Pipe Union for 2106			5
2111	Pipe Union Nut for ditto			9
2112	Petrol Pipe Superior	4	0	
2113	Petrol Pipe Carrier	4	0	
2114	Rubber Tee			9
2116	Tank and Carrier Bolts			3
2117	Lock Washers			2
2118	Nuts			2
2119	Filter for 2105	1	8	
2122	Filter for 2106	1	8	
2123	Cork Seats			6
2124	Guide Screw for Plunger			3
2125	Superior Tank	4	10	0
2126	Oil Measure and Filler Cap		3	6
2127	Transfer, Right or Left (Each)	4	0	
2128	Fixing Bolts			4
2129	Open Frame Tank, complete	4	10	0

SADDLES, TOOLS & ACCESSORIES

PART NO.	DESCRIPTION	£	s.	d.
2202	Seat Pillar	2	10	
2207	Tool Bag	3	0	
2208	Box Spanners and Tommy Bar	5	0	
2211	Pump and Connection	5	6	
2215	Saddle	1	10	0
2216	Spring			1
2217	Coil Spring	3	7	
2219	Cylinder Stud Spanner	1	6	
2220	Cone Spanner			9
2221	Electric Horn	1	2	6
2221A	Battery Container		7	6
2221B	Switch		2	6
2222	Smith Chronometric Speedometer	3	3	6
2222A	Flex Drive	14	6	
2222B	Gear Box and Bracket	1	6	0
2222C	Drive Ring Screws and Plates			10
2228	Bells			4
2229	Grease Guns			5
2230	Clutch Withdrawal Tool	1	10	0
2232	Crank Pin Extractor	2	15	0
2233	Clutch Sleeve Holder			11
2234	Flywheel Steady Spanner (Not G.M.)			6
2235	Flywheel Puller Genimag	15	0	
2236	Flywheel Steady Genimag	3	6	

TRANSMISSION GROUP


PART NO.	DESCRIPTION	£	s.	d.
2301	Bracket Shell Cover	6		6
2302	Bracket Shell			
2305	Bracket Shell Cover Joint			3
2306	Bracket Shell Screw			2
2307	Bracket Shell Lock Washer			2
2307A	Bracket Shell Fibre Washer			3
2308	Worm Wheel	18		0
2309	Worm Wheel Centre	15		0
2310	Worm Wheel Cones	8		6
2310A	Worm Wheel Distance Washer			3
2310B	Oil Throwers			1
2311	Worm Wheel Cup	11		0
2312	Cup Felt Rings			5
2313	$\frac{1}{2}$ " Steel Balls. Set of 40			9
2314	Six Adjusting Shims, 0.005" thick			9
2314B	Six Adjusting Shims, 0.015" thick	1		6
2315	Cup Lock Plate			2
2316	Cup Lock Plate Screw, 2BA $\times \frac{3}{8}$ "			2
2317	Cup Lock Plate Washer, $\frac{3}{16}$ "			2
2318	Crank Axle	6		3
2319	Crank Axle Bush	8		0
2320	Vee-point Plunger	1		1
2321	Locking Plunger	1		1
2322	Plunger Spring			7
2323	Worm Shaft	1		5
2324	Worm Shaft Front Bush	4		3
2325	Gaco Packing	1		6
2328	Nut for Worm Shaft			4
2329	Washers for ditto			2
2330	Thrust Race Housing	6		6
2331	Thrust Race Housing Joint			3
2332	Thrust Race Housing Cap	2		6
2333	Thrust Race Housing Cap Joint			3
2334	Thrust Race Housing Bush	4		3
2335	Thrust Race Housing Screw, B.S.F. $\frac{1}{4}$ " $\times \frac{3}{4}$ "			2
2336	Lock Washer			2
2337	Ball Thrust Washer, W. $\frac{1}{2}$ "	15		0
2338	Power Chain Sprocket	9		6
2339	Power Chain Sprocket Circlip			3
2340	Power Chain Sprocket Fibre Washer			3
2341	Clutch Housing Clamp Bolt, $\frac{1}{4}$ " $\times 1\frac{1}{2}$ "			4
2342	Nut for ditto			3
2343	Pedal Chain, $\frac{1}{8}$ " $\times \frac{1}{8}$ " $\times 113$	5		0
2344	Connection Link			6
2345	Jockey Sprocket	3		6
2346	Bracket for ditto			9
2347	Pedals	8		6
2349	Power Chain, $\frac{1}{2}$ " $\times \frac{3}{16}$ " $\times 112$	4		9
2350	Connection Link			6
2351	Chain Adjuster Cap and Nut			9
2352	Chain Wheel and Crank	12		6
2353	Left-hand Crank	4		6
2354	Cotter Pin Washer and Nut			6
2355	Dipstick	2		8

FRONT WHEEL GROUP MK. 30F.

PART NO.	DESCRIPTION	£ s. d.
2410	Spindle Washer, $\frac{3}{8}$ " \times $\frac{7}{8}$ " \times $\frac{1}{16}$ "	2
2412	Rim, 36 holes	8 0
2413	Short Spokes, 12g \times 10, $\frac{3}{16}$ " with Nipples and Washers	3
2414	Long Spokes, 12g \times 10, $\frac{11}{16}$ " with Nipples and Washers	3
2451	Hub Lubricators	4
2452	Free Wheel, 18T \times $\frac{1}{2}$ " \times $\frac{3}{16}$ " wide	5 0
2453	Cable Clip	4
2454	Cover, 26" \times 2" \times $1\frac{3}{4}$ "	15 10
2455	Tubes, 26" \times 2" \times $1\frac{3}{4}$ "	4 2
2456	Tape	3
2463	Front Wheel complete with Brake	2 0 0
2464	Brake Plate with Anchor Arm, Cam Bush and Fulcrum Pin	9 0
2465	Brake Shoes with Liners	5 6
2466	Brake Shoe Springs	4
2467	Hub Shell and Drum	13 6
2468	Brake Cam Bush	1 4
2469	Brake Cam complete	3 6
2471	Cable Ball Nipple	3
2472	Cable Adjuster	1 4
2473	Fulcrum Pin	7
2474	Felt Washer	3
2475	Steel Washer for Felt	3
2476	Hub End Cap	4
2477	Hub Cups	9
2479	Cone Lock Nut	3
2480	Side Plate Lock Nut	3
2481	Adjusting Cone	1 8
2482	Fixed Cone	1 8
2483	Spindle only	1 6
2486	Liners and Rivets	5 6

REAR WHEEL GROUP MK. 46R.

PART NO.	DESCRIPTION	£	s.	d.
2487	Rear Wheel complete with Brake	3	5	0
2488	Brake Plate, fitted with Anchor Arm Cam Bush and Fulcrum Pin	1	2	0
2490	Cable Adjuster and Nut	1	1	6
2491	Cable Ball Nipples			3
2492	Brake Cam complete	3	6	6
2493	Brake Cam Lever	4	0	
2494	Shackle and Pin for Cam Lever	1	0	
2495	Brake Shoes with Linings	9	6	6
2495A	Brake Liners and Rivets	5	6	6
2496	Brake Shoe Springs			4
2497	Hub Shell and Drum	1	1	5
2498	Spindle only	3	0	
2489	Fixed Cones	1	8	
2500	Adjusting Cones	1	8	
2501	Lock Nut			3
2502	Spindle Nut			3
2504	Distance Piece	1	0	8
2505	Distance Piece Nut... ..			8
2506	Ball Bearings, $\frac{1}{4}$ " Diam.			9
2507	Dust Caps			9
2508	Felt Washer			3
2509	Hub Cups			9
2510	Steel Washer for Felt			3
2511	Anchorage Clip with Pin and Nut	1	0	
2512	Fulcrum Pin			7
2513	Chain Ring	12	0	
2514	Spindle Nut Washer			2
2515	Short Spokes with Nipples and Washers			3
2516	Long Spokes with Nipples and Washers			3





3106



3105

3114



3104



3102



3101





3113



3132



2230




3119

3123



3122



3110

LAST



3112



3110



3111



3110




3112



3110



3111



3110

FIRST



3124



3128




3107



3108



3109




3135



3115



3117



2233

CLUTCH ASSEMBLY SEQUENCE

1556



1557



1555



1555



1551



1549



1554



1550



1553



1555



1572



1586



1587



1596



1560

1579




1570



1584



1593



1577



1576



1548



1547



1567

1563



1562



1568



1561

1581



1594

1595



1570



1569

1582

1658

1653

1657

1656

1655

1663



1663

1665

1662

1666

1643



1664

1661

1660

1668



1691




1685

1699

1686

1687

1673



1683



1689

1695

1692

1681


1656

1694

1656

1682


1676/7/8



1672

1679

1688



1698 PAIR

1695

1697

1670

1680


1681

1664

1693

1687

1671




1659

1690

1675

1664


1674




1669

1664

1674







2221



2002



2222



2221A



2021

2015/6

2022



1596



2222A



2208



2220



2222B



2219



2221B



2279




2211






2222C






2223




2224









IMPORTANT.

WHEN ORDERING SPARES PLEASE STATE:

1. ENGINE NUMBER.
2. QUANTITY REQUIRED.
3. DESCRIPTION.
4. PART NUMBER.

EXAMPLE :

ENGINE No. J 2498.

2 PISTON RINGS, No. 602.

6 COIL ASSEMBLY, No. 1605.

21 LOCK WASHERS, No. 1815.

"SCOTT" CYC-AUTO

REVISED PRICES FOR SPARE PARTS BOOK

Effective as from 1st January, 1951

	P/No.	Description	Price
			£ s. d.
Mark II T Engine Group:	309	Bronze bush for crankcase, fwd. half	0 2 6
	310	Bronze bush for crankcase, rear half	0 2 6
	403	Crank pin 15/- ...	0 10 2
	501	Connecting rod comp. with bush ...	0 18 10
	502	Connecting rod small end bush ...	0 2 0
	504	Connecting rod big end rollers ...	0 5 0
	601	Piston	0 18 0
	602	Piston rings each	0 3 6
	604	Gudgeon pin	0 4 3
	605	Circlips... .. each	0 0 5
	606	Piston (over-size)	0 19 0
607	Piston Rings (over-size)	0 4 0	
702	Cylinder Head Gasket	0 2 10	
Clutch Group:	3105	Clutch spring	0 2 8
	3106	Clutch withdrawal sleeve 15/- ...	0 10 2
	3109	Clutch drive lock bush ... 1/6d ...	0 10 2
	3110	Clutch friction rings	0 1 7
	3111	Clutch plate large	0 1 7
	3112	Clutch plate small	0 1 7
	3117/8	Clutch Brake Lining/Rivets 4/10d ...	0 10 2
	3120	Bush for withdrawal yoke	0 1 7
	3122	Clutch thrust ring	0 10 3
	3124	Clutch operating lever	0 8 3
	3132	Clutch driving shaft £1.5.0d	0 10 2
	3135	Clutch driving shaft bush	0 3 6
	Silencer Group :	1411	Silencer (Black)
1411		Silencer (Chrome)	1 5 0
Spring Fork Group:	1759	Spring fork complete... ..	4 10 0
Mudguard Group:	1825	Front mudguard	0 10 3
	1840	Rear mudguard	0 11 6
Handlebar Group:	1948	Front brake cable	0 7 0
	1949	Rear brake cable	0 7 0
	1957	Clutch cable and adjuster	0 8 3
Transmission Group:	2308	Worm wheel £1.10.0d	1 10 0
	2309	Worm wheel centre £1.5.0d ...	1 5 0
	2310	Worm wheel cones	0 10 3
	2311	Worm wheel cups	0 13 6
	2313	$\frac{1}{2}$ in. steel balls 2/-	0 10 2
	2318	Crank axle	0 8 6
	2319	Crank axle bush	0 14 9
	2324	Worm shaft front bush	0 7 6
	2334	Thrust race housing bush	0 7 6
	2338	Power chain sprocket	0 12 3
	2343	Pedal chain, $\frac{1}{2}$ in. \times $\frac{1}{8}$ in. \times 113 ...	0 7 0 7/6d
2349	Power chain, $\frac{1}{2}$ in. \times $\frac{3}{16}$ in. \times 112 ...	0 8 6	