

THE

# Excelsior

## SPARE PARTS LIST

FOR

98 c.c. "CONSORT"

(Model F.4)

•

1953/54 Model

•

The Excelsior Motor Co. Ltd.

Head Office and Works

Kings Road, Tyseley

Birmingham 11

Telephone: ACOCKS GREEN 1677-8-9

Telegrams: "MONARCH HAYMILLS"

*Printed in England at*

INSTITUTE PRINTING WORKS LTD., BIRMINGHAM 14.

PRICE ONE SHILLING AND SIXPENCE

ISSUED 1/11/53

THE  
**Excelsior**

**SPARE PARTS LIST**

FOR

**98 c.c. "CONSORT"**  
(Model F.4)

•

**1953/54 Model**

•

**The Excelsior Motor Co. Ltd.**


Head Office and Works

**Kings Road, Tyseley**

**Birmingham 11**

Telephone: ACOCKS GREEN 1677-8-9

Telegrams: "MONARCH HAYMILLS"



The 98 c.c. "CONSORT"  
Model F4

## Spare Parts and Service Department

OUR SPARES AND SERVICE DEPARTMENT is always available for advice, service and spares, and we invite all EXCELSIOR owners to take full advantage of the facilities offered.

Much trouble and delay will be saved if the following points are noted:—

**SPARES :** WHEN ORDERING, GIVE FULL DETAILS AS TO MODEL, YEAR OF MANUFACTURE, ENGINE AND FRAME NUMBERS (WITH PREFIX LETTERS). If possible with old machines, send the old parts as patterns. Remittances should include sufficient to cover postage.

**REPAIRS :** Machines or components must be sent **CARRIAGE PAID**, with a label attached bearing the sender's full name and address. A covering letter should be sent giving detailed instructions as to whether an **ESTIMATE** is required, or whether we may proceed with the work immediately.

**REPLACEMENTS UNDER GUARANTEE :** Any defective part must be sent with the request to be replaced free of charge, stating engine and frame numbers, the name and address of the Dealer from whom it was obtained, and the date of purchase. We do not undertake to **FIT** such replacement parts, and if you wish to send the complete machine, the Mechanic's Time in dismantling and re-assembling will be charged for. Carriage both ways to be paid by the Sender.

Any machines or components sent not complying with the above procedure, will remain **AWAITING IDENTIFICATION AT SENDER'S RISK**.

**REMITTANCES.** Cheques and Postal Orders should be made out to "THE EXCELSIOR MOTOR CO. LTD." and crossed "& Co."

**C.O.D. SERVICE.** Spares may be despatched C.O.D. if required.

**ALL PRICES** and **SPECIFICATIONS** are subject to alteration without notice.

Spare Parts and  
 Service Department

OUR SPARE AND SERVICE DEPARTMENT  
 has a full stock of all the parts and accessories  
 for all the models of the ...

which you will find in the following  
 list ...

THE ...  
 ...

...

...

...

...

...

...

...

...

...

...

...

**FRAME**

| Part No. | Description                        | No. off | £  | s. | d. |
|----------|------------------------------------|---------|----|----|----|
| 25065    | Frame Assembly only. Enamelled ... | 1       | 11 | 0  | 0  |
| 1224     | " Cup Races ...                    | 2       |    | 1  | 9  |
| 1543     | " " Balls ... Set of               | 42      |    | 1  | 6  |
| 25035    | Engine Bolt Front ...              | 1       |    |    | 8  |
| 25036    | " " Bottom and Rear ...            | 2       |    |    | 8  |
| 18001    | " " Washer ...                     | 6       |    |    | 1  |
| 17002    | " " Nut ...                        | 3       |    |    | 3  |
| 1457     | " " Cable Clip ...                 | 1       |    |    | 9  |
| 25070    | Centre Stand Assembly only ...     | 1       | 1  | 5  | 0  |
| 25024    | " " Pivot Bolt ...                 | 2       |    |    | 9  |
| 17002    | " " " Nut ...                      | 2       |    |    | 3  |
| 18001    | " " " Washer ...                   | 4       |    |    | 1  |
| 25031    | " " Spring ...                     | 1       |    |    | 10 |
| 25033    | " " Clip ...                       | 1       |    |    | 9  |
| 17001    | " " " Nut ...                      | 1       |    |    | 2  |
| 18017    | " " " Washer ...                   | 1       |    |    | 1  |

**FOOTRESTS**

|       |                     |   |  |   |   |
|-------|---------------------|---|--|---|---|
| 25072 | Footrest Hanger ... | 2 |  | 4 | 0 |
| 1962  | " Rubber ...        | 2 |  | 1 | 9 |

**FRONT FORK ASSEMBLY**

|        |                                  |   |    |   |    |
|--------|----------------------------------|---|----|---|----|
| 25073  | Front Fork Assembly complete ... | 1 | 4  | 7 | 6  |
| ULW1   | Fork Girder only ...             | 1 | 2  | 1 | 6  |
| 4551   | " Spring ...                     | 1 |    | 8 | 6  |
| 4553   | " " Top Nut ...                  | 1 |    |   | 3  |
| 4548   | " Links ... Per Set of           | 4 |    | 9 | 4  |
| 4823   | " Spindles. Bottom ...           | 2 |    | 2 | 4  |
| 4549   | " " Top ...                      | 2 |    | 2 | 0  |
| 2958   | " " Nut ...                      | 4 |    |   | 3  |
| 4560/L | " " Washer. Large ...            | 6 |    |   | 1  |
| 4560/S | " " " Small ...                  | 2 |    |   | 1  |
| ULW2   | Crown and Column ...             | 1 | 11 |   | 6  |
| 2966   | " " " Dome Nut ...               | 1 |    | 1 | 9  |
| 25046  | " " " Lock Stop Buffers ...      | 2 |    | 1 | 0  |
| 1224   | Crown Steering Race ...          | 1 |    | 1 | 9  |
| 1224   | Top Steering Race ...            | 1 |    | 1 | 9  |
| 1352   | " " Cup ...                      | 1 |    | 2 | 9  |
| 4584   | Handlebar Top Clip Lug only ...  | 1 |    | 9 | 6  |
| 1019A  | " Half Clip. Top ...             | 2 |    | 1 | 10 |
| 2806/4 | " " Bolt ...                     | 4 |    |   | 8  |
| 18003  | " " " Washer ...                 | 4 |    |   | 1  |

Note.—Always quote the Model and Engine and Frame Nos.

### Front Fork Assembly—continued

| Part No. | Description             | No. off | £ | s. | d. |
|----------|-------------------------|---------|---|----|----|
| 4606     | Top Clip Clamp Bolt     | 1       | 1 | 2  |    |
| 4607     | " " " Nut               | 1       |   | 3  |    |
| 4650     | " " " Eccentric Sleeve  | 1       |   | 8  |    |
| D233     | Lubricators             | 5       |   | 3  |    |
| 1511     | Headlamp Bracket. Top   | 2       |   | 9  |    |
| 25052    | " " Bottom              | 2       |   | 9  |    |
| 16002    | " " Bolt                | 4       |   | 4  |    |
| 17005    | " " Nut                 | 2       |   | 2  |    |
| 18005    | " " Washer              | 4       |   | 1  |    |
| 4722/1   | Mudguard Bridge         | 1       |   | 4  |    |
| 2444     | " " Bolt and Nut        | 1       |   | 4  |    |
| 16002    | Bridge to Mudguard Bolt | 2       |   | 4  |    |
| 17005    | " " Nut                 | 2       |   | 2  |    |
| 18005    | " " Washer. Small       | 2       |   | 1  |    |
| 18006    | " " " Large             | 2       |   | 1  |    |

### FRONT MUDGUARD AND NUMBER PLATE

|       |   |   |    |   |  |
|-------|---|---|----|---|--|
| 25074 | Front Mudguard complete with Stays, Nuts, Bolts and Washers | 1 | 19 | 0 |  |
| 25050 | Mudguard Blade only   | 1 | 12 | 6 |  |
| 25037 | " Stay. Long  | 2 | 1  | 0 |  |
| 25038 | " " Short   | 2 | 1  | 0 |  |
| 16002 | Mudguard Stay to Blade Bolt                                 | 4 |    | 4 |  |
| 17005 | " " " Nut   | 4 |    | 2 |  |
| 18010 | " " " Washer. Thick   | 4 |    | 1 |  |
| 18005 | Mudguard Stay to Blade Washer. Thin                         | 4 |    | 1 |  |
| 16002 | Mudguard Stay to Fork Leg Bolt                              | 2 |    | 4 |  |
| 18010 | Mudguard Stay to Fork Leg Bolt Washer. Thick                | 2 |    | 1 |  |
| 18005 | Mudguard Stay to Fork Leg Bolt Washer. Thin                 | 2 |    | 1 |  |
| 1159  | Front Number Plate  | 1 | 2  | 0 |  |
| 1160  | Front Number Plate Lug with Nut and Washer                  | 2 |    | 9 |  |
| 16001 | Front Number Plate to Lug Bolt                              | 2 |    | 2 |  |
| 17004 | " " " Nut   | 2 |    | 2 |  |
| 18004 | " " " Washer  | 2 |    | 1 |  |

### REAR MUDGUARD AND NUMBER PLATE

|       |  |   |    |   |   |
|-------|--|---|----|---|---|
| 25075 | Rear Mudguard complete with Stays, Bolts, Nuts and Washers | 1 | 1  | 1 | 6 |
| 25049 | Mudguard Blade only  | 1 | 14 | 0 |   |

Note.—Always quote the Model and Engine and Frame Nos.

### Rear Mudguard and Number Plate—continued.

| Part No. | Description                             | No. off | £ | s. | d. |
|----------|---|---------|---|----|----|
| 25040    | Mudguard Stay. Front                    | 2       | 1 | 0  |    |
| 25039    | " " Rear                                | 2       | 1 | 0  |    |
| 16002    | Mudguard Stay to Blade Bolt             | 4       |   | 4  |    |
| 17005    | " " " Nut                               | 4       |   | 2  |    |
| 18010    | " " " Washer. Thick                     | 4       |   | 1  |    |
| 18005    | " " " Thin                              | 4       |   | 1  |    |
| 16005    | Mudguard Stay to Fork End Bolt          | 2       |   | 4  |    |
| 17001    | " " " Nut                               | 2       |   | 2  |    |
| 18003    | Mudguard Stay to Fork End Washer. Small | 4       |   | 1  |    |
| 18017    | Mudguard Stay to Fork End Washer. Large | 2       |   | 1  |    |
| 16014    | Mudguard Blade to Frame Bolt            | 1       |   | 6  |    |
| 17005    | " " " Nut                               | 1       |   | 2  |    |
| 18006    | " " " Washer                            | 1       |   | 1  |    |
| 16013    | Mudguard Bridge and Saddle Stud         | 2       |   | 8  |    |
| 17001    | " " " Nut                               | 6       |   | 2  |    |
| 18017    | " " " Washer                            | 6       |   | 1  |    |
| 1232     | Rear Number Plate                       | 1       | 4 | 6  |    |
| 16002    | " " " Bolt. Top                         | 2       |   | 4  |    |
| 17005    | " " " Nut. Top                          | 2       |   | 2  |    |
| 18005    | " " " Washer. Top                       | 4       |   | 1  |    |
| 16004    | " " " Bolt. Bottom                      | 1       |   | 5  |    |
| 17005    | " " " Nut. Bottom                       | 2       |   | 2  |    |
| 18005    | " " " Washer. Bottom.                   | 2       |   | 1  |    |

### TOOLBOX

|       |                       |   |   |   |  |
|-------|-----------------------|---|---|---|--|
| 25020 | Toolbox only with lid | 1 | 7 | 6 |  |
| 1194  | " to Frame Clip       | 1 |   | 8 |  |
| 16002 | " " " Bolt            | 2 |   | 4 |  |
| 17005 | " " " Nut             | 2 |   | 2 |  |
| 18005 | " " " Washer          | 2 |   | 1 |  |

### FRONT WHEEL

|       |   |               |                         |    |   |
|-------|---|---------------|-------------------------|----|---|
| 25092 | Front Wheel complete less Tyre and Tube | 1             | 4                       | 10 | 0 |
| 25095 | Wheel Rim                               | 1             | 1                       | 4  | 0 |
| 25093 | Outer Cover, 19" x 2.25"                | 1             | Prices upon application |    |   |
| 25094 | Inner Tube, 19" x 2.25"                 | 1             | application             |    |   |
| 1705  | Rim Band                                | 1             |                         | 1  | 0 |
| 25097 | Spoke, L.H., 7 $\frac{3}{16}$ " x 12g.  | Per Set of 18 |                         | 3  | 0 |
| 25098 | " R.H., 8 $\frac{1}{8}$ " x 12g.        | Per Set of 18 |                         | 3  | 0 |
| 25099 | " Nipples, 12g.                         | Per Set of 36 |                         | 6  | 0 |
| 25096 | Front Hub complete                      | 1             | 2                       | 15 | 0 |

Note.—Always quote the Model and Engine and Frame Nos.

Front Wheel—continued.

| Part No. | Description  | No. off | £  | s. | d. |
|----------|--|---------|----|----|----|
| 20F1     | Hub Shell with Brake Drum only ...   | 1       | 19 | 3  |    |
| 20F2     | Brake Outer Plate complete with Shoes, Springs, Cam and Actuating Lever... | 1       | 1  | 7  | 6  |
| 20F3     | Brake Outer Plate only ...   | 1       | 8  | 9  |    |
| 20F4     | " Shoes with Linings ...   | 1 Pr.   | 12 | 9  |    |
| 20F5     | " Linings and Rivets ...   | 1 Pr.   | 6  | 4  |    |
| 20F6     | " Return Springs ...   | 1 Pr.   | 1  | 2  |    |
| 20F7     | " Cam and Washer ...   | 1       | 2  | 9  |    |
| 20F8     | " Actuating Lever ...  | 1       | 2  | 9  |    |
| 20F9     | Spindle only ...   | 1       | 2  | 3  |    |
| 20F10    | " Cones ...  | 1 Pr.   | 1  | 10 |    |
| 20F11    | Spindle Cups ...   | 2       |    | 9  |    |
| 20F12    | " Balls, 1/4" dia. ... Per Set of  | 18      |    | 9  |    |
| 20F13    | " Dust Washer ...  | 2       |    | 5  |    |
| 20F14    | " Nut ...  | 2       |    | 6  |    |
| 20F15    | " Spacer Nut, 1/4" wide ...  | 2       |    | 4  |    |
| 20F16    | " Adj. Cone Lock Nut ...   | 1       |    | 4  |    |
| 20F17    | " Spacer Brake Side, 1/4" wide ...   | 1       |    | 3  |    |
| 20F18    | " Washers, 1/8" wide ...   | 2       |    | 1  |    |
| 20F19    | " " 1/32" " ...  | 1       |    | 1  |    |
| 20F20    | Lubricator ...   | 1       |    | 6  |    |

REAR WHEEL

|       |  |       |                         |    |   |
|-------|--|-------|-------------------------|----|---|
| 25100 | Rear Wheel complete less Tyre and Tube ...                                 | 1     | 6                       | 5  | 0 |
| 25107 | Wheel Rim ...  | 1     | 1                       | 4  | 0 |
| 25093 | Outer Cover, 19" x 2.25 ...  | 1     | Prices upon application |    |   |
| 25094 | Inner Tube, 19" x 2.25 ...   | 1     | application             |    |   |
| 1705  | Rim Band ...   | 1     | 1                       | 0  |   |
| 25102 | Spoke, L.H., 6 1/2" x 12g. ... Per Set of                                  | 18    | 3                       | 0  |   |
| 25103 | " R.H., 9" x 12g. ... Per Set of   | 18    | 3                       | 0  |   |
| 25099 | " Nipple ... Per Set of  | 36    | 6                       | 0  |   |
| 25101 | Rear Hub complete ...  | 1     | 4                       | 10 | 0 |
| 4TS1  | Rear Hub Shell with Brake Drum and Sprocket ...                            | 1     | 2                       | 2  | 3 |
| 4TS2  | Rear Hub Sprocket with Rivets ...  | 1     | 17                      | 9  |   |
| 4TS3  | Brake Outer Plate complete with Shoes, Springs, Cam and Actuating Lever... | 1     | 1                       | 12 | 6 |
| 4TS4  | Brake Outer Plate only ...   | 1     | 10                      | 0  |   |
| 4TS5  | " Shoes with Linings ...   | 1 Pr. | 14                      | 9  |   |
| 4TS6  | " Linings and Rivets ...   | 1 Pr. | 7                       | 6  |   |
| 4TS7  | " Shoe Return Springs ...  | 1 Pr. | 1                       | 2  |   |
| 4TS8  | " Cam with Nut and Washer ...  | 1     | 4                       | 0  |   |
| 4TS9  | " Actuating Lever ...  | 1     | 3                       | 3  |   |
| 25108 | " Rod Roller ...   | 1     |                         | 6  |   |

Note.—Always quote the Model and Engine and Frame Nos.

Rear Wheel—continued.

| Part No. | Description                       | No. off | £  | s. | d. |
|----------|-----------------------------------|---------|----|----|----|
| 16023    | Brake Anchor Bolt ...             | 1       |    | 7  |    |
| 17001    | " " Nut ...                       | 1       |    | 2  |    |
| 18017    | " " Washer ...                    | 1       |    | 1  |    |
| 4TS10    | Spindle only ...                  | 1       | 4  | 6  |    |
| 4TS11    | " Cones ...                       | 1 Pr.   | 4  | 6  |    |
| 4TS12    | " Cups ...                        | 2       | 1  | 4  |    |
| 20F12    | " Balls, 1/4" dia. ... Per Set of | 20      | 10 |    |    |
| 4TS13    | " Dust Washer ...                 | 2       |    | 9  |    |
| 4TS14    | " Nut ...                         | 2       |    | 7  |    |
| 4TS15    | " Locknut, 1/4" wide ...          | 2       |    | 6  |    |
| 4TS16    | " Spacer, 2" wide ...             | 1       |    | 3  |    |
| 4TS17    | " Washer, 1/8" wide ...           | 2       |    | 1  |    |
| 4TS18    | " " 1/32" wide ...                | 2       |    | 1  |    |
| 20F20    | Lubricator ...                    | 1       |    | 6  |    |
| 1483     | Rear Wheel Adjuster ...           | 2       |    | 1  | 9  |
| 1101     | " " Nut ...                       | 2       |    | 2  | 0  |
| 25104    | Rear Driving Chain, 114P ...      | 1       | 10 | 6  |    |
| 25104A   | " " " Connecting Link ...         | 1       |    | 6  |    |
| 25104B   | " " " Cranked Link ...            | 1       |    | 6  |    |

HANDLEBAR ASSEMBLY

|          |  |   |    |    |  |
|----------|--|---|----|----|--|
| 25087    | Handlebar Bend ...                                       | 1 | 13 | 6  |  |
| 16/117CE | Twist Grip complete ...                                  | 1 | 11 | 0  |  |
| 16/070   | " " Rubber ...   | 1 | 1  | 0  |  |
| 16/011   | " " Split Cable Stop ...                                 | 1 |    | 6  |  |
| 16/008   | " " Friction Spring ...                                  | 1 |    | 9  |  |
| 16/069   | Handlebar Dummy Grip ...                                 | 1 | 1  | 6  |  |
| 25088    | Clutch Lever complete ...                                | 1 | 3  | 11 |  |
| B204/L   | " " Body ...   | 1 | 1  | 0  |  |
| 4857     | Clutch Lever only ...                                    | 1 | 2  | 0  |  |
| B160     | Clutch Lever Fulcrum Pin, Nut and Washer ...             | 1 | 1  | 0  |  |
| B179     | Clutch Lever Handlebar Clip ...                          | 1 |    | 7  |  |
| B174     | Clutch Lever Handlebar Clip Bolt, Nut and Washer ...     | 1 |    | 5  |  |
| 25090    | Clutch Cable complete ...                                | 1 | 3  | 6  |  |
| 25089    | Front Brake Lever complete ...                           | 1 | 3  | 11 |  |
| B204/R   | " " Body ...   | 1 | 1  | 0  |  |
| 4857     | Front Brake Lever only ...                               | 1 | 2  | 0  |  |
| B160     | Front Brake Lever Fulcrum Pin, Nut and Washer ...        | 1 | 1  | 0  |  |
| B179     | Front Brake Lever Handlebar Clip ...                     | 1 |    | 7  |  |
| B174     | Front Brake Lever Handlebar Clip Bolt Nut and Washer ... | 1 |    | 5  |  |
| 25091    | Front Brake Cable complete ...                           | 1 | 3  | 6  |  |

Note.—Always quote the Model and Engine and Frame Nos.

### CHAINGUARD

| Part No. | Description                 | No. off | £  | s. | d. |
|----------|-----------------------------|---------|----|----|----|
| 25042    | Chainguard only             | 1       | 15 | 0  | 0  |
| 16002    | " to Engine Bolt            | 1       |    | 4  |    |
| 18005    | " " Washer                  | 1       |    | 1  |    |
| 16003    | Chainguard to Mudguard Bolt | 1       |    | 5  |    |
| 17005    | " " Nut                     | 1       |    | 2  |    |
| 18006    | " " Washer                  | 2       |    | 1  |    |
| 16002    | Chainguard to Stay Bolt     | 1       |    | 4  |    |
| 17005    | " " Nut                     | 1       |    | 2  |    |
| 18006    | " " Washer                  | 2       |    | 1  |    |

### BRAKE PEDAL ASSEMBLY

|       |                          |   |   |   |  |
|-------|--------------------------|---|---|---|--|
| 25014 | Brake Pedal              | 1 | 8 | 6 |  |
| 25030 | " Spring                 | 1 |   | 9 |  |
| 16004 | " Stop Bolt              | 1 |   | 5 |  |
| 17005 | " " Nut                  | 1 |   | 2 |  |
| 16022 | " Pivot Bolt             | 1 |   | 5 |  |
| 18017 | Brake Pedal Pivot Washer | 1 |   | 1 |  |
| 25048 | Brake Rod                | 1 | 3 | 3 |  |
| 18006 | " Washer                 | 1 |   | 1 |  |
| 1634  | " Cotter                 | 1 |   | 1 |  |
| 25032 | " Spring                 | 1 |   | 6 |  |
| 17005 | " Stop Nut               | 1 |   | 2 |  |
| 25109 | " Adjusting Nut          | 1 | 1 | 0 |  |

### PETROIL TANK

|       |                      |   |   |   |   |
|-------|----------------------|---|---|---|---|
| 25028 | Petroil Tank only    | 1 | 4 | 0 | 0 |
| 1577  | Filler Cap and Chain | 1 |   | 5 | 9 |
| 1813  | Oil Measure          | 1 |   | 2 | 0 |
| 1732  | Transfer             | 2 |   | 7 |   |
| 1997  | Tank Balance Pipe    | 1 | 4 | 6 |   |
| 1739  | " " Union            | 2 | 1 | 6 |   |
| 1296  | " " Fibre Washer     | 2 |   | 1 |   |
| 25105 | Fuel Tap             | 1 | 6 | 0 |   |
| 1296  | " Fibre Washer       | 1 |   | 1 |   |
| 1998  | Petroil Feed Pipe    | 1 | 4 | 9 |   |
| 25045 | Tank Fixing Bolt     | 2 |   | 6 |   |
| 17001 | " Nut                | 2 |   | 2 |   |
| 18017 | " Washer             | 4 |   | 1 |   |

### SADDLE

|        |                     |    |   |    |   |
|--------|---------------------|----|---|----|---|
| 25044  | Saddle complete     | 1  | 1 | 18 | 6 |
| W125/1 | " Top only          | 1  |   | 18 | 0 |
| W125/2 | " Rear Coil Springs | 2  |   | 3  | 0 |
| W125/3 | " Mattress Springs  | 13 |   | 4  |   |

Note.—Always quote the Model and Engine and Frame Nos.

### EXHAUST SYSTEM

| Part No. | Description      | No. off | £ | s. | d. |
|----------|------------------|---------|---|----|----|
| 25053    | Exhaust Pipe     | 1       |   | 1  | 0  |
| 25081    | Silencer         | 1       |   | 17 | 6  |
| 17001    | " Attachment Nut | 1       |   |    | 2  |
| 18017    | " " Washer       | 1       |   |    | 1  |

### TOOL KIT AND EQUIPMENT

|       |                                |   |    |   |   |
|-------|--------------------------------|---|----|---|---|
| 25113 | Tool Kit complete with Holdall | 1 | 13 | 6 |   |
| 1622  | " " Holdall                    | 1 |    | 4 | 6 |
| 1626  | Four Hole Spanner              | 1 |    | 9 |   |
| 1623  | 6" Screwdriver                 | 1 |    | 1 | 0 |
| 1624  | Small Screwdriver              | 1 |    | 9 |   |
| 1723  | Plug Spanner                   | 1 |    | 2 | 6 |
| 25112 | Magneto Spanner                | 1 |    | 1 | 3 |
| 1724  | Tyre Lever                     | 1 |    | 1 | 0 |
| 25111 | Hub Nut Spanner                | 1 |    | 1 | 9 |
| 1610  | Inflator                       | 1 |    | 5 | 6 |
| 1611  | Bulb Horn complete             | 1 |    | 7 | 6 |
| 1612  | Licence Holder complete        | 1 |    | 2 | 6 |
| 18017 | " Spacing Washer               | 1 |    |   | 1 |
| 2070  | H.T. Cable Suppressor          | 1 |    | 2 | 6 |

### LIGHTING SET

#### HEADLAMP

|        |                                       |        |   |    |    |
|--------|---------------------------------------|--------|---|----|----|
| 060088 | Headlamp complete with Wiring Harness | 1      | 3 | 14 | 0  |
| 608157 | Rim only, less glass                  | 1      |   | 12 | 6  |
| 600308 | Wire for Glass Fixing                 | 4 set  |   |    | 8  |
| 612220 | Packing for Glass                     | 1      |   |    | 2½ |
| 612103 | Glass                                 | 1      |   | 1  | 9  |
| 612171 | Main Bulb Holder                      | 1      |   | 6  | 6  |
| 608025 | Pilot " "                             | 1      |   |    | 6  |
| 612172 | Reflector                             | 1      |   | 11 | 6  |
| 31157A | Lighting Switch U.39L18               | 1      |   | 10 | 6  |
| 31278  | Dip Switch No. 99                     | 1      |   | 6  | 6  |
| CM.2   | Cable Grommet                         | Per 10 |   | 1  | 6  |
| 182511 | Lamp Fixing Nut                       | 2      |   |    | 6  |
| 188471 | Shakeproof Washer                     | Per 10 |   |    | 6  |
| 612218 | Rim Catch Spring                      | 1      |   |    | 3  |
| 612217 | Rim Catch                             | 1      |   |    | 1  |
| 188818 | Terminal Sleeve                       | Per 10 |   |    | 9  |
| 612222 | Battery Contact                       | Per 10 |   |    | 2  |

Note.—Always quote the Model and Engine and Frame Nos.

### Headlamp—continued.

| Part No. | Description                       | No. off | £          | s. | d. |
|----------|-----------------------------------|---------|------------|----|----|
| 180      | Main Bulb, 6v. 18/18 watt S.B.C.  | 1       | 4          | 6  |    |
|          |                                   |         | +9d. P.T.  |    |    |
| 974      | Pilot Bulb, 3.5v. .15 amp. M.E.S. | 1       | 9          |    |    |
|          |                                   |         | +14d. P.T. |    |    |
| 351567   | Switch Handle                     | 1       | 3          | 0  |    |
| 101593   | " " Screw                         | Per 10  | 2          | 0  |    |

### TAIL LAMP

|       |                              |   |           |   |  |
|-------|------------------------------|---|-----------|---|--|
| 1765  | Tail Lamp complete           | 1 | 12        | 6 |  |
| 1680  | Back Plate                   | 1 | 3         | 0 |  |
| R.114 | Rubber for Back Plate        | 1 | 9         |   |  |
| 16016 | Back Plate Fixing Screws     | 3 | 1         |   |  |
| 17010 | " " " " Nut                  | 3 | 1         |   |  |
| R.117 | Rubber Sealing Washer        | 1 | 3         |   |  |
| 1681  | Perspex Lens                 | 1 | 2         | 0 |  |
| 1682  | Lens Holder, Plated          | 1 | 3         | 3 |  |
| 16022 | " " Fixing Screws            | 2 | 2         |   |  |
| 2049  | Tail Lamp Lead, Single       | 1 | 9         |   |  |
| 1684  | Connection Seal              | 1 | 6         |   |  |
| 1685  | Spring                       | 1 | 3         |   |  |
| 1686  | Bulb. 6v. $\frac{1}{2}$ watt | 1 | 4         |   |  |
|       |                              |   | +3d. P.T. |   |  |
| 1849  | Lead Junction Box            | 1 | 3         |   |  |
| 1767  | " Spring Clips               | 4 | 5         |   |  |

### ENGINE PARTS

|          |  |   |   |    |    |
|----------|--|---|---|----|----|
| E3907    | Cylinder Head Bolt                           | 4 |   | 11 |    |
| E5808    | Washer                                       | 4 |   | 3  |    |
| C7263    | Cylinder Head                                | 1 | 1 | 0  | 10 |
| E8546    | Gasket                                       | 1 |   | 5  |    |
| B7261F/1 | Cylinder                                     | 1 | 3 | 5  | 0  |
| E4453    | Exhaust Nut Washer                           | 1 |   | 4  |    |
| E3934    | " Nut  | 1 | 1 | 8  |    |
| Type 6/0 | Carburettor complete with Control and Filter |   | 3 | 6  | 8  |
| E7168    | Cylinder Base Gasket                         | 1 |   | 5  |    |
| C7045    | Piston complete with Bushes (Standard size)  | 1 | 1 | 6  | 0  |
| D7515    | Piston as above, .015" oversize              | 1 | 1 | 6  | 0  |
| D7517    | " " " .030" "                                | 1 | 1 | 6  | 0  |

Note.—Always quote the Model and Engine and Frame Nos.

### Engine Parts—continued.

| Part No. | Description                                 | No. off | £  | s. | d. |
|----------|---|---------|----|----|----|
| E6141    | Piston Ring, Standard size                  | 2       | 2  | 3  |    |
| E7516    | " " .015" oversize                          | 2       | 2  | 3  |    |
| E7518    | " " .030" "                                 | 2       | 2  | 3  |    |
| E8272    | Expander Ring                               | 1       | 1  | 4  |    |
| E7198    | Gudgeon Pin                                 | 1       | 3  | 3  |    |
| E5218    | Circlip                                     | 2       |    | 5  |    |
| D7494    | Connecting Rod, .001" oversize (Bushed)     | 1       | 19 | 6  |    |
| E6192    | Small End Bush                              | 1       | 3  | 3  |    |
| E7452    | Rollers for Crankpin                        | 28      |    | 3  |    |
| E7493    | Crankpin, .001" oversize                    | 1       | 5  | 10 |    |
| D7971    | Crankshaft—Right-hand                       | 1       | 1  | 19 | 0  |
| C7875    | " —Left-hand                                | 1       | 19 | 6  |    |
| E5124    | Engine Sprocket Key                         | 1       | 4  |    |    |
| E4873    | Flywheel Key                                | 1       | 4  |    |    |
| 6205     | Crankshaft Ball Bearing                     | 2       | *  |    |    |
| MIS.012  | Oil Seal                                    | 2       | 2  | 7  |    |
| A3235    | Gaco Oil Seal                               | 1       | 4  | 7  |    |
| E6725    | Engine Sprocket                             | 1       | 9  | 1  |    |
| E7197    | Lockwasher                                  | 1       | 5  |    |    |
| E6930    | Nut   | 1       | 1  | 6  |    |
| 110037   | Primary Chain, 56 pitches                   | 1       | *  |    |    |
| B7936    | Crankcase Door                              | 1       | 1  | 9  | 3  |
| D8547    | " " Gasket                                  | 1       | 7  |    |    |
| E363     | Studs for Cylinder Base                     | 4       | 4  |    |    |
| E1050    | Spring Washer                               | 4       | 3  |    |    |
| E3961    | Nut   | 4       | 3  |    |    |
| E7271    | Screw for Crankcase Door                    | 2       | 7  |    |    |
| E7128    | " " " "                                     | 4       | 5  |    |    |
| E3222    | Crankcase Drain Plug and Clutch-bridge Bolt | 2       | 8  |    |    |
| V476     | Washer, Drain Screw                         | 1       | 3  |    |    |
| E2924    | " Plain                                     | 1       | 1  |    |    |
| A7935    | Cover, Left-hand side                       | 1       | 19 | 6  |    |
| E7915    | Screw for Cover                             | 1       | 8  |    |    |
| E4934    | " " " "                                     | 1       | 4  |    |    |
| E6567    | Clutch Lever Adjusting Screw                | 1       | 8  |    |    |
| E7765    | Locknut                                     | 1       | 3  |    |    |
| D6546    | Clutch Lever                                | 1       | 3  | 3  |    |
| A8008    | Gearcase                                    | 1       | 3  | 5  | 0  |
| C7170    | Clutchcase Gasket                           | 1       | 8  |    |    |
| A7959    | Clutchcase                                  | 1       | 2  | 18 | 6  |
| E7619    | Dowels in Gearcase and Clutchcase           | 4       | 4  |    |    |
| E8015    | Dowel in Gearcase for Crankcase Door        | 1       | 4  |    |    |
| E7271    | Screw securing Clutchcase to Gearcase       | 2       | 7  |    |    |

\* Manufacturers' Current Price

Note.—Always quote the Model and Engine and Frame Nos.



Engine Parts—continued.

| Part No.     | Description                                  | No. off | £  | s. | d. |
|--------------|--|---------|----|----|----|
| E4104        | Oil Filler Plug                              | 1       | 1  | 1  |    |
| V107 × 3     | Washer                                       | 1       |    | 3  |    |
| —            | Flywheel Assembly complete with Leads        |         |    |    |    |
| 1148 × 4 c/p | High Tension Lead                            | 1       | 5  | 10 |    |
| M2110        | Rubber Cover for Terminal Holder             | 1       |    | 5  |    |
| M2099        | High Tension Terminal Holder                 | 1       | 1  | 8  |    |
| E869         | Felt Washer                                  | 1       |    | 4  |    |
| 5/8" No. 2   | Brass Terminal Screw                         | 1       |    | 3  |    |
| M2105        | " " Spring                                   | 1       |    | 4  |    |
| M2104        | Terminal Spring Pad                          | 1       |    | 4  |    |
| M2123        | Adaptor for Contact Breaker                  | 1       | 7  | 2  |    |
| E8180        | Screw securing Adaptor to Crankcase Door     | 3       |    | 3  |    |
| M2368        | Gasket for Adaptor                           | 1       |    | 3  |    |
| —            | Contact Breaker Assembly and Cam Lubricator  |         |    |    |    |
| M2262        | Condenser                                    | 1       | 5  | 10 |    |
| M1670        | Screw securing Condenser to Crankcase Door   | 1       |    | 4  |    |
| 1113 × 5     | Washer                                       | 1       |    | 1  |    |
| M2276        | Distance Piece                               | 1       |    | 1  |    |
| E1962        | Oil Level Plug                               | 1       |    | 5  |    |
| E1905        | Washer                                       | 1       |    | 3  |    |
| E7326        | Screws securing Clutchcase to Gearcase       | 5       |    | 4  |    |
| E7129        | Screws securing Flywheel Cover to Clutchcase | 3       |    | 8  |    |
| E7915        | Screws securing Flywheel Cover to Clutchcase | 1       |    | 4  |    |
| A7960        | Flywheel Cover                               | 1       | 2  | 8  | 9  |
| E7217        | Bush for Kickstarter Shaft                   | 1       |    | 3  | 11 |
| D7246        | Kickstarter Lever                            | 1       | 11 | 1  |    |
| E4096        | " Pedal                                      | 1       | 5  | 10 |    |
| E4098        | " " Pivot Pin                                | 1       |    | 8  |    |
| E4270        | " " Spring                                   | 1       |    | 3  |    |
| 1/2" dia.    | " " Ball                                     | 1       |    | 3  |    |
| E4251        | Clamp Bolt for Kickstart Lever               | 1       |    | 9  |    |
| E4252        | Nut  | 1       |    | 4  |    |
| E7224        | Kickstarter Return Spring                    | 1       |    | 1  | 1  |
| E7232        | " " Cover                                    | 1       |    | 1  | 8  |
| D7704        | " Shaft                                      | 1       | 1  | 0  | 10 |
| E7706        | Bush in Clutchcase for Kickstarter Shaft     | 1       |    | 2  | 0  |
| D8116        | Gasket, Kickstart Cover                      | 1       |    | 4  |    |
| E7222        | Kickstarter Stop Pin                         | 1       |    | 5  |    |
| E3961        | Nut for Stop Pin                             | 1       |    | 3  |    |

Note.—Always quote the Model and Engine and Frame Nos.

Engine Parts—continued.

| Part No. | Description  | No. off      | £ | s. | d. |
|----------|--|--------------|---|----|----|
| E1050    | Spring Washer  | 1            |   |    | 3  |
| E6552    | Circlip  | 1            |   |    | 4  |
| E7221/1  | Spring Retaining Washer                                | 1            |   |    | 5  |
| E7223/1  | Spring   | 1            |   |    | 4  |
| E7220/1  | Kickstarter Ratchet                                    | 1            |   | 7  | 10 |
| E7219    | " Pinion   | 1            |   | 10 | 5  |
| 6004     | Ball Bearing   | 1            |   |    | *  |
| E7609    | Splined Lockwasher                                     | 1            |   |    | 8  |
| E7073    | Clutch Spring Retaining Nut                            | 1            |   | 1  | 4  |
| E5558/1  | " Spring   | 1            |   | 1  | 6  |
| E5556    | " " Locating Bush                                      | 1            |   | 2  | 0  |
| D5433    | Outer Clutch Plate, Right-hand                         | 1            |   | 6  | 10 |
| D5232    | Clutch Sprocket with cork inserts                      | 1            |   | 15 | 0  |
| E4960    | Large Clutch Cork for Clutch Sprocket and Corked Plate | 25           |   |    | 1  |
| E5220    | Small Clutch Cork for Clutch Sprocket only             | 5            |   |    | 1  |
| E4955    | Side Plate for Clutch Sprocket Ball Bearing            | 2            |   |    | 7  |
| E5001    | Rivet for Plate  | Per set of 5 |   |    | 3  |
| E4948    | Ball Race  | 1            |   | 2  | 11 |
| 1/2"     | Ball   | 33           |   |    | 9  |
| D4954    | Centre Clutch Plate, dished                            | 1            |   | 6  | 10 |
| D5233    | Clutch Plate, with cork inserts                        | 1            |   | 7  | 6  |
| D4951    | Outer Clutch Plate, Left-hand                          | 1            |   | 6  | 10 |
| E7454    | Circlip  | 1            |   | 1  | 0  |
| E7072    | Splined Washer, brass                                  | 1            |   | 1  | 0  |
| E7057/1  | Low Gear Wheel   | 1            |   | 15 | 7  |
| E8130    | Sliding Dog Clutch                                     | 1            |   | 11 | 1  |
| E7056    | High Gear Wheel  | 1            | 1 | 4  | 9  |
| 6005     | Ball Bearing   | 1            |   |    | *  |
| E7882    | Distance Piece   | 1            |   | 2  | 0  |
| A3235    | Oil Seal   | 1            |   | 4  | 7  |
| E7881    | Driving Sprocket                                       | 1            |   | 9  | 1  |
| E6930    | Retaining Nut  | 1            |   | 1  | 6  |
| E5561    | Locking Screw for Retaining Nut                        | 1            |   |    | 4  |
| 4 B.A.   | Spring Washer  | 1            |   |    | 1  |
| C7215    | Clutch Shaft   | 1            | 1 | 4  | 9  |
| E7270/1  | " Cotter   | 1            |   | 2  | 0  |
| E4945    | " Push Rod, short                                      | 1            |   |    | 9  |
| E7196    | " " long   | 1            |   |    | 1  |
| E7060    | Countershaft Spindle                                   | 1            |   | 5  | 10 |
| E7063    | " Washer   | 1            |   | 1  | 8  |
| E7058    | " Bushed   | 1            | 1 | 0  | 10 |
| E7061/1  | " Bush   | 2            |   | 2  | 0  |

\* Manufacturers' Current Price

Note.—Always quote the Model and Engine and Frame Nos.

Engine Parts—continued.

| Part No.  | Description                        | No. off | £  | s. | d. |
|-----------|------------------------------------|---------|----|----|----|
| E7269     | Countershaft Bridge                | 1       | 2  | 7  |    |
| E4251     | " " Bolt                           | 2       |    | 9  |    |
| E4252     | Nut                                | 2       |    | 4  |    |
| E1050     | Spring Washer                      | 2       |    | 3  |    |
| E8131     | Gear Selector Lever                | 1       | 5  | 10 |    |
| E7195     | Pivot Pin, Selector                | 1       |    | 4  |    |
| E8132     | Gear Operating Plate               | 1       | 3  | 3  |    |
| E7071/1   | Spindle for Selector Lever         | 1       | 1  | 0  |    |
| E7066     | Stop Pin                           | 1       |    | 8  |    |
| E7067     | Forked Joint for Gear Selector     | 1       | 2  | 7  |    |
| E7092     | Gear Selector Spring               | 1       |    | 5  |    |
| E7070     | Pin securing Forked Joint to Lever | 1       |    | 8  |    |
| E421      | Split Pin for above                | 1       |    | 1  |    |
| E7381     | Gear Selector Cable complete       | 1       | 9  | 1  |    |
| E7491     | Inner Cable (with Nipple E7199)    | 1       | 2  | 3  |    |
| E7492     | Outer Cable with Ferrules          | 1       | 3  | 3  |    |
| E8098     | Cable Adjusting Sleeve             | 1       | 1  | 0  |    |
| V683      | " " Screw                          | 2       |    | 9  |    |
| V105 × 2  | Locknut                            | 3       |    | 3  |    |
| V105 × 1  | Cable Adjuster at Control Lever    | 1       |    | 9  |    |
| E7199     | " Nipple at Engine end             | 1       |    | 5  |    |
| E7404     | " " Lever end                      | 1       |    | 3  |    |
| E7068     | Guide for Forked Joint             | 1       | 2  | 0  |    |
| E7456     | Gear Control Lever Assembly        | 1       | 15 | 0  |    |
| V117 × 5  | Screw for Gear Control Body        | 1       |    | 8  |    |
| E7211     | Top Cover Plate                    | 1       | 1  | 8  |    |
| V142 × 11 | Spring Washer                      | 1       |    | 4  |    |
| V142 × 9  | Friction Plate                     | 1       |    | 8  |    |
| V142 × 10 | Fibre Washer                       | 2       |    | 4  |    |
| E7200     | Gear Control Lever                 | 1       | 3  | 11 |    |
| V142 × 1  | " " Body                           | 1       | 4  | 7  |    |
| V142 × 7  | " " Clip                           | 1       | 2  | 0  |    |
| V142 × 5  | Screw for Clip                     | 2       |    | 3  |    |

**CARBURETTER PARTS**

|           |                                    |   |   |    |  |
|-----------|------------------------------------|---|---|----|--|
| V117 × 5  | Screw for Carburetter Control Body | 1 |   | 8  |  |
| V387      | Top Cover Plate                    | 1 | 1 | 8  |  |
| V142 × 11 | Spring Washer                      | 1 |   | 4  |  |
| V429      | Friction Plate                     | 1 |   | 8  |  |
| V142 × 10 | Fibre Washer                       | 2 |   | 4  |  |
| V406      | Carburetter Control Lever          | 1 | 3 | 11 |  |
| V405      | " " Body                           | 1 | 4 | 7  |  |
| V142 × 7  | " " Clip                           | 1 | 2 | 0  |  |
| V142 × 5  | Screw for Clip                     | 2 |   | 3  |  |

Note.—Always quote the Model and Engine and Frame Nos.

Carburetter Parts—continued.

| Part No.  | Description  | No. off | £  | s. | d. |
|-----------|--|---------|----|----|----|
| V667      | Control Cable Assembly                               | 1       |    | 6  | 6  |
| V105 × 1  | Control Cable Adjuster                               | 1       |    | 9  |    |
| V105 × 2  | Locknut  | 1       |    | 3  |    |
| V108 × 4  | Control Cable Sleeve                                 | 1       |    | 5  |    |
| V123 × 15 | Nipple, Control end                                  | 1       |    | 3  |    |
| V145 × 16 | " Carburetter end                                    | 1       |    | 3  |    |
| V367      | Top Ring   | 1       |    | 1  | 8  |
| V368      | Top Disc with Guide Peg                              | 1       | 2  | 0  |    |
| V413      | Adjuster for Taper Needle                            | 1       |    | 8  |    |
| V651      | Taper Needle, No. 2½                                 | 1       | 1  | 4  |    |
| V107 × 7  | " Spring   | 1       |    | 4  |    |
| V369      | Throttle Spring                                      | 1       |    | 8  |    |
| V365      | Throttle   | 1       | 2  | 11 |    |
| V408      | Centrepiece with Jet, No. J.120                      | 1       | 5  | 3  |    |
| V107 × 3  | Fibre Washer   | 1       |    | 3  |    |
| V424      | Locating Screw for Centrepiece                       | 1       |    | 4  |    |
| V649      | Carburetter Body, with Fuel Needle Lever and Bush    | 1       | 12 | 4  |    |
| V207      | Tickler  | 1       |    | 7  |    |
| V369      | " Spring   | 1       |    | 8  |    |
| V111 × 2  | " Split Pin  | 1       |    | 1  |    |
| V326      | Clip securing Carburetter to Stub on Cylinder Barrel | 1       | 2  | 7  |    |
| V107 × 16 | Screw for Clip                                       | 1       |    | 8  |    |
| EM653     | Air Filter with Clip                                 | 1       | 7  | 2  |    |
| EM618     | " " Clip   | 1       | 2  | 0  |    |
| E5 102    | Bolt for Clip  | 1       |    | 4  |    |
| 1002 × 15 | Nut  | 1       |    | 3  |    |
| V382      | Banjo Union Bolt                                     | 1       | 1  | 4  |    |
| H104 × 8  | Washer, large hole                                   | 1       |    | 4  |    |
| V404      | Gauze Filter   | 1       |    | 8  |    |
| V383      | Washer, small hole                                   | 1       |    | 4  |    |
| V381      | Banjo Union  | 1       | 2  | 3  |    |
| V107 × 2  | Joint Washer, Float Cup                              | 1       |    | 8  |    |
| V107 × 1  | Float  | 1       |    | 4  | 7  |
| V146 × 6  | " Cup  | 1       |    | 4  | 3  |
| V107 × 4  | Washer for Bottom Nut                                | 1       |    | 3  |    |
| V581      | Bottom Nut   | 1       | 1  | 4  |    |
| V355      | Fuel Needle  | 1       |    | 1  | 0  |

**CONTACT BREAKER AND CAM GREASER PARTS**

|       |                               |   |   |    |  |
|-------|-------------------------------|---|---|----|--|
| M2118 | Contact Breaker Point Bracket | 1 | 2 | 7  |  |
| M2141 | Rocker Arm Assembly           | 1 | 5 | 10 |  |
| M2122 | " Pivot Pin                   | 1 |   | 7  |  |

Note.—Always quote the Model and Engine and Frame Nos.

**Contact Breaker and Cam Greaser Parts—continued.**

| Part No.    | Description                          | No. off | £ | s. | d. |
|-------------|--------------------------------------|---------|---|----|----|
| E5257       | Rocker Pivot Pin Washer              | 1       |   |    | 3  |
| V111 × 2    | Split Pin                            | 1       |   |    | 5  |
| M1801       | Screw for Point Bracket              | 1       |   |    | 1  |
| M1802       | Washer, Brass                        | 1       |   |    | 3  |
| M2138       | Low Tension Terminal Bush            | 1       |   |    | 7  |
| 1113 × 5    | Washer                               | 1       |   |    | 1  |
| EM1001      | Nut                                  | 1       |   |    | 1  |
| 1047 × 3    | Spring                               | 1       |   |    | 4  |
| M1805       | Insulating Washer                    | 1       |   |    | 3  |
| 1113 × 5    | Washer                               | 1       |   |    | 1  |
| M2120       | Low Tension Terminal Screw           | 1       |   |    | 4  |
| E8151       | Felt Greaser Pad for Contact Breaker |         |   |    |    |
|             | Cam                                  | 1       |   |    | 5  |
| E8150       | Clip for Greaser Pad                 | 1       |   |    | 4  |
| ½" × No. 4A | Screws for Clip                      | 2       |   |    | 1  |

**MAGNETO PARTS**

|          |   |        |   |    |      |
|----------|---|--------|---|----|------|
| M2156    | Flywheel  | 1*     |   |    |      |
| M2159    | Centre  | 1*     |   |    |      |
| M2160    | Nut   | 1*     |   |    |      |
| M1226    | Screws  | 6*     | 5 | 4  | 0    |
| M2152    | Magnets   | 6*     |   |    |      |
| M2237    | Pole Pieces   | 6*     |   |    |      |
| M2269    | Plates  | 6      |   |    | 4    |
| 1002 × 9 | Screws  | 12     |   |    | 4    |
| A128     | Armature Plate Assembly   | 1      | 4 | 11 | 0    |
| E5102    | Securing Screws   | 4      |   |    | 4    |
| M2346    | Twin Lighting Coils complete with Leads to Sockets on Engine Casing | 1 pair | 1 | 11 | 3    |
| M2275    | Clip securing Lighting Lead to Armature Plate                       | 1      |   |    | 5    |
| M2151    | Ignition Coil   | 1      | 1 | 6  | 0    |
| M2158    | End, R.H.   | 1      |   |    | 3 11 |
| M2264    | "    L.H.   | 1      |   |    | 3 11 |
| M2366    | Low Tension Lead and Shoe (rubber covered cable)                    | 1      | 1 |    | 0    |
| 1124 × 9 | Screw for Ignition and Lighting Coil Ends                           | 6      |   |    | 4    |
| M2240    | Screw for Ignition Coil Ends  | 2      |   |    | 3    |
| L315     | Small Socket for Lighting Lead                                      | 1      | 2 |    | 0    |
| L316     | Large "    "  | 1      | 2 |    | 0    |
| E8548    | Locking Plate for Sockets   | 1      |   |    | 4    |
| L1286    | Twin Plug for Lighting Lead   | 1      | 2 |    | 11   |

\* Not supplied separately

**Note.**—Always quote the Model and Engine and Frame Nos.

**Guarantee**

**NOTICE**

We do not appoint agents for the sale on our behalf of our Motor Cycles or other goods but we assign to Motor Cycle Dealers areas in which we supply to such dealers exclusively for re-sale in such areas. No such Dealer is authorised to transact any business, give any warranty, make any representation or incur any liability on our behalf.

**CONDITIONS OF SALE AND GUARANTEE**

We give the following guarantee with our motor cycles, motor cycle combinations and sidecars including all accessories and component parts other than tyres, saddles, chains and lighting and electrical equipment and other than accessories and component parts supplied to the order of the Purchaser and differing from those comprised in the standard specifications supplied with our motor cycles, motor cycle combinations and sidecars, but including accessories and parts supplied by way of exchange as hereinafter provided. This guarantee is given in place of any implied conditions or warranties or any liabilities whatsoever, statutory or otherwise; no guarantee except that hereinafter contained and no condition or warranty whatsoever statutory or otherwise is given or is to be implied, nor are we to be under any liability whatsoever except under the guarantee hereinafter contained. Any statement, description, condition or representation contained in any catalogue advertisement, leaflet or other publication shall not be construed as enlarging, varying or over-riding anything herein contained. In the case of machines (a) which have been used for "hiring out" purposes or (b) any motor cycle and/or sidecar used for any dirt track, cinder track or grass track racing or competitions (or any competition of any kind within an enclosure for which a charge is made for admission to take part in or view the competition) or (c) machines from which the trade mark, name or manufacturing number has been altered or removed or (d) any machine in which parts have been used not supplied by or approved by the motor cycle manufacturer, or (e) any machine from which the silencing system as fitted by the manufacturer has been partially or wholly removed or interfered with, no guarantee, condition or warranty of any kind statutory or otherwise is given or is to be implied nor are we to be under any liability whatsoever in respect of such machines.

We guarantee, subject to the conditions mentioned below, that all precautions which are usual and reasonable have been taken by us to secure excellence of materials and workmanship, but this guarantee is to extend and be in force for six months only from date of purchase, or date of exchange in case of any accessory or part supplied by way of exchange as hereinafter provided, and damages for which we make ourselves responsible under this guarantee are limited to the free repair of or supply of a new part or accessory in exchange for the part of the motor cycle, motor cycle combination or sidecar or accessory which may have proved defective. We undertake, subject to the conditions mentioned below, to make good in manner aforesaid any part or accessory covered by this guarantee which has proved defective within the said period of six months. We do not undertake to replace or refix, or bear the cost of replacing or refixing any such new part or accessory in the motor cycle, motor cycle combination or sidecar. As motor cycles, motor cycle combinations and sidecars are easily liable to derangement by neglect or misuse, this guarantee does not apply to defects caused by wear and tear, misuse or neglect.

The term "misuse" shall include amongst others the following act—The use of a motor cycle when carrying more persons or greater weight than that for which the machine was designed by the manufacturer.

We do not guarantee tyres, saddles, chains or lighting and electrical equipment, or any accessories or component parts supplied to the order of the Purchaser differing from those comprised in the standard specifications supplied with our motor cycles, motor cycle combinations or sidecars. As regards all such tyres, saddles, chains, lighting and electrical equipment, accessories and component parts, no guarantee, condition or warranty of any kind statutory or otherwise is given or is to be implied, and we are to be under no liability whatsoever in respect thereof.

**CONDITIONS OF GUARANTEE.**

If a defective part or accessory should be found in our motor cycles, motor cycle combinations or sidecars or in any part or accessory supplied by way of exchange as before provided, it must be sent to us CARRIAGE PAID and accompanied by an intimation from the owner that he desires to have it repaired or exchanged free of charge under our guarantee, and he must also furnish us at the same time with the number of the machine, the date of the purchase or the date when the alleged defective part or accessory was exchanged as the case may be.

Failing compliance with the above, such articles will lie here at THE RISK OF THE OWNER, and this guarantee and any implied guarantee, warranty or condition shall not be enforceable. All machines are despatched Carriage Paid to nearest Railway Station in Great Britain.

